



Configuração de Internet - Modo PPPoE


DIR-600

DIR-600



Procedimentos para configuração de Internet - Modo PPPoE

1- Para realizar o procedimento de configuração em modo **PPPoE** o computador deve estar conectado via cabo Ethernet em uma das portas LAN do DIR-600 e o seu Cable Modem ou Modem ADSL em modo **Bridge*** conectado na Porta Internet do Roteador DIR-600.



*Para que o Roteador DIR-600 navegue na internet utilizando a configuração em modo PPPoE, o Modem ADSL deve estar configurado em modo Bridge. Para saber se o seu Modem utiliza essa configuração basta verificar se com ele ligado direto ao computador você necessita de um discador de banda larga com nome de usuário e senha do provedor de acesso

Obs.: Para realizar estes procedimentos não é necessário estar conectado à internet.

2- Acesse agora a página de configuração do Roteador. Abra o Internet Explorer e digite na barra de endereços <http://192.168.0.1> e tecla Enter.



Será apresentada a tela de autenticação para acesso a página de configuração.

A screenshot of the D-Link router login page. At the top, it says 'Product Page : DIR-600' and 'Hardware Version : B1 Firmware Version : 2.00'. Below this is the D-Link logo. The main section is titled 'LOGIN' and contains the text 'Log in to the router:'. There are three input fields: 'User Name' with 'admin' entered, 'Password' (empty), and a CAPTCHA field. The CAPTCHA text is 'below. HTDMF' and is highlighted with a red box. Below the CAPTCHA is a 'Regenerate' button. At the bottom is a 'Log In' button.

O usuário e senha padrão do equipamento são:

Nome de Usuário: Admin

Senha: *(deixe em branco)*

Confirme os caracteres no campo Below

Clique em **Login**.

3- Com a tela de configuração aberta clique no botão **Internet Setup** localizado à esquerda da página e logo em seguida no botão **Manual Internet Connection Setup** no final da tela.

Product Page : DIR-600 Hardware Version : B1 Firmware Version : 2.00

D-Link®

DIR-600 //	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP
-------------------	--------------	-----------------	--------------------	---------------	-------------

Internet Setup

Wireless Setup

LAN Setup

Time and Date

Parental Control

Logout

INTERNET CONNECTION

If you are configuring the device for the first time, we recommend that you click on the Internet Connection Setup Wizard button and follow the instructions on the screen. If you wish to modify or configure the device settings manually, click the Manual Internet Connection Setup button.

INTERNET CONNECTION SETUP WIZARD

If you would like to utilize our easy to use Web-based Wizard to assist you in connecting your new D-Link Systems Router to the Internet, click on the button below.

Internet Connection Setup Wizard

Note: Before launching the wizard, please make sure you have followed all steps outlined in the Quick Installation Guide included in the package.

MANUAL INTERNET CONNECTION OPTIONS

If you would like to configure the Internet settings of your new D-Link Router manually, then click on the button below.

Manual Internet Connection Setup

Helpful Hints..

- If you are new to networking and have never configured a router before, click on **Internet Connection Setup Wizard** and the router will guide you through a few simple steps to get your network up and running.
- If you consider yourself an advanced user and have configured a router before, click **Manual Internet Connection Setup** to input all the settings manually.

4- Em seguida vai abrir a tela de configuração manual de Internet.

No campo **Access Point Mode** deixe a opção **Enable Access Point Mode** desmarcada. E no campo **My Internet Connection is:** selecione a opção **PPPoE (username/Password)**.

Product Page : DIR-600 Hardware Version : B1 Firmware Version : 2.00

D-Link

DIR-600 // SETUP ADVANCED MAINTENANCE STATUS HELP

Internet Setup
Wireless Setup
LAN Setup
Time and Date
Parental Control
Logout

INTERNET CONNECTION

Use this section to configure your Internet Connection method. There are several connection methods to choose from: Static IP, DHCP, PPPoE, PPTP, L2TP, Russian PPTP(Dual Access) and Russian PPPoE(Dual Access). If you are unsure of your connection method, please contact your Internet Service Provider.

Note: If using the PPPoE option, you will need to remove or disable any PPPoE client software on your computers.

Save Settings Don't Save Settings

ACCESS POINT MODE

Use this to disable NAT on the router and turn it into an Access Point.

☐ Enable Access Point Mode

INTERNET CONNECTION TYPE

Choose the mode to be used by the router to connect to the Internet.

My Internet Connection is : PPPoE (Username / Password)

PPPOE

Enter the information provided by your Internet Service Provider (ISP).

☒ Dynamic PPPoE ☐ Static PPPoE

User Name : dlinklab@globo.com

Helpful Hints..

- Internet Connection:** When configuring the router to access the Internet, be sure to choose the correct **Internet Connection Type** from the drop down menu. If you are unsure of which option to choose, please contact your **Internet Service Provider (ISP)**.
- Support:** If you are having trouble accessing the Internet through the router, double check any settings you have entered on this page and verify them with your ISP if needed.

[Link...](#)

5- Na tela de configuração **PPPoE**, nos campos:

INTERNET CONNECTION TYPE

Choose the mode to be used by the router to connect to the Internet.

My Internet Connection is : PPPoE (Username / Password)

PPPOE

Enter the information provided by your Internet Service Provider (ISP).

☒ Dynamic PPPoE ☐ Static PPPoE

User Name : dlinklab@globob.com **1**

Password : *****

Confirm Password : *****

Service Name : (optional)

IP Address :

MAC Address : - - - - - (optional)

Clone MAC Address

☒ Receive DNS from ISP ☐ Enter DNS Manually

Primary DNS Address : 10.1.1.1

Secondary DNS Address : (optional)

Maximum Idle Time : 5 Minutes

MTU : 1492

Connect mode select : ☒ Always ☐ Manual ☐ Connect-on demand New Schedule **2**

3

Save Settings Don't Save Settings

Username: **Digite o seu nome de usuário com o provedor de acesso à Internet.**

Password: **Digite sua senha para este usuário.**

Confirm Password: **Repita a senha.**

Connect mode select: Selecione a opção **Always**.

Clique no botão **Save Settings** para salvar a configuração.

6- Para verificar se está com acesso à internet acesse a guia **Status** e verifique se na faixa de **WAN** ou **INTERNET** o campo **IP Address** obteve algum endereço IP, caso apresente 0.0.0.0, clique no botão **Conect** e verifique se agora existe um endereço IP. Confirme o acesso à internet acessando um site de sua preferência.

Product Page : DIR-600 Hardware Version : B1 Firmware Version : 2.00

D-Link

DIR-600 // SETUP ADVANCED MAINTENANCE **STATUS** HELP

Device Info Log Statistics Active Session Wireless Logout

DEVICE INFORMATION

All of your Internet and network connection details are displayed on this page. The firmware version is also displayed here.

Firmware Version : 2.00 , Tue 14 Apr 2009

LAN

MAC Address : 00:21:91:50:8c:3a
IP Address : 192.168.0.1
Subnet Mask : 255.255.255.0
DHCP Server : Enabled

INTERNET

MAC Address : 00:21:91:50:8c:3b
PPPoE Connected
Connection :
IP Address : 201.0.37.55
Subnet Mask : 255.255.255.255
Default Gateway : 201.0.37.55
DNS : 200.204.0.10 200.204.0.138

WIRELESS 802.11N

SSID : teste
Channel : 11
Encryption : Disabled

Helpful Hints...
• All of your LAN, Internet and WIRELESS 802.11 N connection details are displayed here.

