

MODENS USB SUPORTADOS*		
GSM	· Alcatel X500	· Huawei E173 (Megafon)
	· D-Link DWM-152C1	· Huawei E220
	· D-Link DWM-156A6	· Huawei E3131 (MTS 420S)
	· D-Link DWM-156A7	· Huawei E352 (Megafon)
	· D-Link DWM 156A8	· Huawei E3531
	· D-Link DWM-156C1	· Prolink PHS600
	· D-Link DWM-157B1	· Prolink PHS901
	· D-Link DWM-157B1 (Velcom)	· ZTE MF112
	· D-Link DWM-158D1	· ZTE MF192
	· D-Link DWR-710	· ZTE MF626
	· Huawei E150	· ZTE MF627
	· Huawei E1550	· ZTE MF652
	· Huawei E156G	· ZTE MF667
	· Huawei E160G	· ZTE MF668
	· Huawei E169G	· ZTE MF752
	· Huawei E171	
LTE	· Alcatel IK40V	· Megafon M150-3
	· D-Link DWM-222	· Quanta 1K6E (Beeline 1K6E)
	· Huawei E3131	· MTS 824F
	· Huawei E3272	· MTS 827F
	· Huawei E3351	· Yota LU-150
	· Huawei E3372s	· Yota WLTUBA-107
	· Huawei E3372h-153	· ZTE MF823
	· Huawei E3372h-320	· ZTE MF823D
	· Huawei E367	· ZTE MF827
	· Huawei E392	· ZTE MF833T
	· Megafon M100-1	· ZTE MF833V
	· Megafon M100-2	
	· Megafon M100-3	
	· Megafon M100-4	
	· Megafon M150-1	
	· Megafon M150-2	

* A D-Link não garante o bom funcionamento do roteador com cada modificação/versão de firmware dos modems USB.